



S2、S1、S0 开启内部上拉电阻

PC5 输出PWM，每0.5s改变一次PWM占空比
(0% --> 100% --> 50% --> 25% 循环)

S2_S1_S0 = 000 PWM_output_40KHz

S2_S1_S0 = 001 PWM_output_20kHz

S2_S1_S0 = 010 PWM_output_10kHz

S2_S1_S0 = 011 PWM_output_5KHz

S2_S1_S0 = 100 PWM_output_2KHz

S2_S1_S0 = 101 PWM_output_1KHz

S2_S1_S0 = 110 PWM_output_500Hz

S2_S1_S0 = 111 PWM_output_250Hz

Title		
Size	Number	Revision
B		
Date:	28-Dec-2017	Sheet of
File:	工程文件 原理图文件 MyDesign.ddb	Drawn By: